# OEL Recommended Spare Parts List

## OKIFAX 4550/OKIOFFICE 87

Revision 9

| Rev | Unit Name | No. | Part No. | Part Name | Q'ty /Unit | Recommended Q'ty/Year | | | Remarks | Del/ Add | ks for environment |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | per 500 | per 1000 | per 2000 | | | |
| | CABINET ASSEMBLY | 3a | YA4116-1228G001 | LED HEAD GENERAL SPEC. 31B | 1 | 1 | 2 | 4 | OKIFAX4550 | | - |
| | CABINET ASSEMBLY | 3b | 40521101 | LED Head Unit-51J | 1 | 1 | 2 | 4 | OKIOFFICE87 | | - |
| | CABINET ASSEMBLY | 4a | 41016104 | Cable-Flat-Assy | 1 | 5 | 10 | 20 | For OKIFAX 4550 THAI production | | - |
| | CABINET ASSEMBLY | 4b | 41686801 | Cord-LED_Assy. | 1 | 5 | 10 | 20 | OKIOFFICE87 | | - |
| | CABINET ASSEMBLY | 8b | 40588901 | DC POWER SUPPLY UNIT(230V) | 1 | 5 | 10 | 20 | | | - |
| | CABINET ASSEMBLY | 9a | 41821601 | Board-46F-2 spare parts collected spec. | 1 | 3 | 6 | 12 | For OKIFAX 4550 UK production Includes Item 41016104_Cable-Flat_Assy. and 41255802_Board-46F-2. | | - |
| | CABINET ASSEMBLY | 9b | 41345201 | Board-R46 | 1 | 3 | 6 | 12 | OKIOFFICE87 | | - |
| | CABINET ASSEMBLY | 9c | 41255802 | Board-46F-2 | 1 | 3 | 6 | 12 | For OKIFAX 4550 THAI production | | - |
| | CABINET ASSEMBLY | 10a | 41143501 | Board-EN9 | 1 | 3 | 6 | 12 | OEL(Europe) | | - |
| | CABINET ASSEMBLY | 10c | 41172901 | Board-G4N | 1 | 3 | 6 | 12 | ISDN | | - |
| | CABINET ASSEMBLY | 10f | 41143905 | Board-INU | 1 | 3 | 6 | 12 | NO-EC (East Europe) | | - |
| | CABINET ASSEMBLY | 11 | 40605601 | H.V. Board P6L | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 13 | 40672901 | Plate Assy.-Base(A) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 14 | 40023901 | Bracket-Package | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 15 | 40236401 | Plate Assy.-Shield(HV) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 17 | 41767002 | Frame Assy.-Scanner L | 1 | 3 | 6 | 12 | 300dpi | | - |
| | CABINET ASSEMBLY | 18a | 41766703 | Frame Assy.-Scanner(U) | 1 | 3 | 6 | 12 | OKIFAX 4550 | | - |
| | CABINET ASSEMBLY | 18b | 41766704 | Frame Assy.-Scanner(U) | 1 | 3 | 6 | 12 | OKIOFFICE87 | | - |
| | CABINET ASSEMBLY | 21 | 40606501 | Cover-Main(A) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 22 | 40025301 | Cover-Front | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 24 | 40606601 | Cover-Rear(A) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 25 | 40672801 | Cover Assy.-Top(A) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 26 | 40026101 | Spring-TC | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 27 | 40024001 | Guide-Paper(U) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 28 | PP4083-6168P001 | HEAD SPRING | 2 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 29 | 40024101 | Guide-Paper(L) | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 36 | 40773601 | Sheet-Shield(LED) | 1 | 3 | 6 | 12 | OKIFAX 4550 | | - |
| | CABINET ASSEMBLY | 39 | 40140801 | Bracket-Damper | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 40 | 42596601 | Damper-Oil | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 41 | 40025701 | Tray-Document | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 42 | 40025801 | Tray-Paper | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 43 | 40375801 | Stacker Assy.-Document | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 55 | 41345101 | Cap-TEL_IF | 1 | 3 | 6 | 12 | | | - |
| | CABINET ASSEMBLY | 56 | 41725701 | Clamp-Cable | 2 | 5 | 10 | 20 | OKIOFFICE87 | | - |

| Rev | Unit Name | No. | Part No. | Part Name | Q'ty /Unit | Recommended Q'ty/Year | | | Remarks | Del/ Add | ks for environment |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | per 500 | per 1000 | per 2000 | | | |
| | UNIT-PRINTER | 5 | 40607401 | H.V. Board P2H | 1 | 5 | 10 | 20 | | | - |
| | UNIT-PRINTER | 6 | 40413401 | Cover-HV | 1 | 3 | 6 | 12 | | | - |
| | UNIT-051 OPE PANEL | 1 | 41766901 | OP Panel Assy.-Partial | 1 | 3 | 6 | 12 | ODA/OEL/INT TENOVIS Include Item No.13-2:40040001 Connection Cord-Wire(OPE). | | - |
| | UNIT-051 OPE PANEL | 2a | 40682804 | Sheet-Function | 1 | 3 | 6 | 12 | OKIFAX 4550 OEL/INT | | - |
| | UNIT-051 OPE PANEL | 2b | 01006911 | Sheet-F-046 | 1 | 3 | 6 | 12 | OKIFAX 4550 GER | | - |
| | UNIT-051 OPE PANEL | 2c | 01017809 | Sheet-F-046-ISDN | 1 | 3 | 6 | 12 | OKIFAX 4550 ISDN OEL/INT | | - |
| | UNIT-051 OPE PANEL | 2d | 01017811 | Sheet-F-046-ISDN | 1 | 3 | 6 | 12 | OKIFAX 4550 ISDN GER | | - |
| | UNIT-051 OPE PANEL | 2f | 01034609 | Sheet-F-046 | 1 | 3 | 6 | 12 | OKIOFFICE87 GER | | - |
| | UNIT-051 OPE PANEL | 3a | 41254701 | Sheet-O-051_2net | 1 | 10 | 20 | 40 | ODA/OEL/INT | | - |
| | UNIT-052 OPE PANEL | 3b | 01012704 | Film-OP panel | 1 | 10 | 20 | 40 | German | | - |
| | UNIT-053 OPE PANEL | 4 | 40023601 | Sheet-Cover | 1 | 5 | 10 | 20 | | | - |
| | OPE PANEL ASSEMBLY | 2 | 40086701 | Board-04W | 1 | 3 | 6 | 12 | | | - |
| | OPE PANEL ASSEMBLY | 3 | 40023001 | Holder-LCD | 1 | 3 | 6 | 12 | | | - |
| | OPE PANEL ASSEMBLY | 4 | 40023101 | Button-Function | 4 | 6 | 12 | 24 | | | - |
| | OPE PANEL ASSEMBLY | 5 | PP4120-1067P001 | TEN KEY | 1 | 3 | 6 | 12 | | | - |
| | OPE PANEL ASSEMBLY | 6a | 40023201 | Button-Start | 1 | 3 | 6 | 12 | OKI,TENOVIS | | - |
| | OPE PANEL ASSEMBLY | 7a | 40023301 | Button-Stop | 1 | 3 | 6 | 12 | OKI,TENOVIS | | - |
| | OPE PANEL ASSEMBLY | 9 | YB4134-1009P001 | LCD | 1 | 3 | 6 | 12 | | | - |
| | OPE PANEL ASSEMBLY | 11 | PB4120-1113P001 | RUBBER CONNECTOR | 2 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 2 | 40019401 | Lever-PC1 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 3 | 40019501 | Lever-PC2 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 4 | 40019601 | Roller Assy.-ADF | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 5 | 40020201 | Plate-Earth ADF | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 6 | 40020601 | Piece-Exit | 2 | 6 | 12 | 24 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 7 | 40020703 | Spring-Exit | 2 | 6 | 12 | 24 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 8 | 40127501 | CONN Cord-Speaker | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 9 | 40141401 | Contact Image Sensor | 1 | 3 | 6 | 12 | 300dpi | | - |
| | FRAME ASSEMBLY-SCANNER L | 10 | 40644701 | Film-Guide(CIS) | 2 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 14 | 40020301 | Gear-Z95/14 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 15 | 40020501 | Spring-Latch | 2 | 6 | 12 | 24 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 18 | 40153801 | Spring-Reinforcement | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 19 | 40025201 | Gear-Z38 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 20 | 40024501 | Spring-CIS | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 21 | 41667901 | Plate-Earth_CIS | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER L | 22 | 41734401 | Foam-Shielding | 2 | 6 | 12 | 24 | | | - |

| Rev | Unit Name | No. | Part No. | Part Name | Q'ty /Unit | Recommended Q'ty/Year | | | Remarks | Del/ Add | ks for environment |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | per 500 | per 1000 | per 2000 | | | |
| | FRAME ASSEMBLY-SCANNER L | 23 | 40899901 | Spring-Reinforcement_add_work | 1 | 3 | 6 | 12 | | | - |
| | PLATE ASSEMBLY-SCANNER(B) | 3 | 40135301 | Photo-Interrupter | 2 | 6 | 12 | 24 | | | - |
| | PLATE ASSEMBLY-SCANNER (R) | 2 | YB4120-1036P001 | S MOTOR-151/175 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 2 | PP3527-5153P001 | BACK-UP PLATE | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 3 | 40267001 | Separator Assy.-ADF | 1 | 5 | 10 | 20 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 5 | 40021401 | Spring-Pinch(L) | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 6 | 40021501 | Spring-Pinch(R) | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 7a | 40745801 | Guide-Sensor(A) | 1 | 3 | 6 | 12 | OKIFAX 4550 | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 7b | 40745802 | Guide-Sensor(A) | 1 | 3 | 6 | 12 | OKIOFFICE87 | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 8a | 40021701 | Guide-Sensor(B) | 2 | 6 | 12 | 24 | OKIFAX 4550 | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 8b | 40021702 | Guide-Sensor(B) | 2 | 6 | 12 | 24 | OKIOFFICE87 | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 9 | 40481101 | Spring-ADF(048) | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 10 | 40199101 | Cord-Earth | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 12 | 40021202 | Roller Assy.-Sensor | 1 | 5 | 10 | 20 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 13 | 40022001 | Bearing-S | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 14 | 40020801 | Gear-Z31 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 16 | 40026301 | Bar-Discharge | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 17 | 40461301 | Film-Exit(DOC) | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 19 | 1051002C0001 | TR-13-7-6 | 1 | 3 | 6 | 12 | | | - |
| | FRAME ASSEMBLY-SCANNER(U) | 20 | 41592101 | Tape-Insulation | 1 | 3 | 6 | 12 | L=200mm | | - |
| | COVER ASSEMBLY-TOP | 2 | 40606701 | Holder-LED(A) | 1 | 3 | 6 | 12 | | | - |
| | COVER ASSEMBLY-TOP | 5 | 40022601 | Spring-D | 1 | 3 | 6 | 12 | | | - |
| | COVER ASSEMBLY-TOP | 6 | PP4128-1268P001 | PLATE EXIT | 2 | 6 | 12 | 24 | | | - |
| | COVER ASSEMBLY-TOP | 7 | PP4083-2024P001 | EJECT ROLLER A | 2 | 6 | 12 | 24 | | | - |
| | COVER ASSEMBLY-TOP | 8 | PP4083-2328P003 | PINION GEAR B | 1 | 3 | 6 | 12 | | | - |
| | PLATE ASSEMBLY-BASE | 3 | 40606901 | Sheet-Insulation(A) | 1 | 3 | 6 | 12 | | | - |
| | PLATE ASSEMBLY-BASE | 4 | 40128001 | Cord-Flat(FUJI CARD) | 1 | 5 | 10 | 20 | | | - |
| | PRINTER BASE FRAME UNIT | 1 | 40593201 | Frame Unit Assy | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 3 | PP4083-1191P001 | SENSOR PAPER E | 2 | 6 | 12 | 24 | | | - |
| | PRINTER BASE FRAME UNIT | 4 | 40721301 | Separator Assy | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 6 | 40781701 | Spring Compression S | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 7 | PA4083-1193G001 | SENSOR ASSY TONER | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 8 | 40496401 | Motor-Pulse | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 11 | 40779601 | Roller Hopping | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 12 | PP4083-1128P001 | HOLDER ROLLER H | 1 | 3 | 6 | 12 | | | - |

| Rev | Unit Name | No. | Part No. | Part Name | Q'ty /Unit | Recommended Q'ty/Year | | | Remarks | Del/ Add | ks for environment |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | per 500 | per 1000 | per 2000 | | | |
| | PRINTER BASE FRAME UNIT | 13 | PB4083-1127P001 | MAGNET H. | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 14 | PA4083-1133G001 | SHAFT HOPPING ASSY | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 15 | NK2-10-SUS | KNOCK PIN | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 16 | PP4083-1143P001 | GEAR IDLE R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 17 | PP4083-1184P001 | IDLE GEAR 2R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 18 | PP4083-1142P001 | GEAR R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 19 | PP4083-1181P001 | GEAR IDLE M | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 20 | PP4083-1189P001 | PLATE EARTH A | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 21 | PP4083-1188P001 | PLATE SIDE M | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 22 | PP4083-1182P001 | GEAR IDLE P | 2 | 6 | 12 | 24 | | | - |
| | PRINTER BASE FRAME UNIT | 23 | 40721001 | Gear-Idle-3R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 24 | PP4083-1165P001 | PLATE TENSION | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 25 | PP4083-1185P001 | GEAR IDLE HEAT | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 26 | PP4083-1186P001 | GEAR IDLE EA | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 27 | PP4083-1187P001 | GEAR IDLE EB | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 28 | PP4083-1170P001 | SHAFT DRIVE E | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 29 | 40074601 | Roller Eject | 2 | 6 | 12 | 24 | | | - |
| | PRINTER BASE FRAME UNIT | 30 | PP4083-1141P001 | BEARING REGIST | 5 | 17 | 35 | 70 | | | - |
| | PRINTER BASE FRAME UNIT | 31 | PB4083-1140P001 | ROLLER REGIST | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 32 | 41802101 | Film-Guide_F | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 33 | 40737801 | Gear-T | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 34 | 40713601 | Roller-Transfer | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 35 | PP4083-1136P001 | SPRING PRESSURE L | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 36 | PP4083-1161P001 | BEARING BU | 2 | 6 | 12 | 24 | | | - |
| | PRINTER BASE FRAME UNIT | 37 | 40594601 | Roller Pressure B | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 38 | PP4083-1233P001 | GUIDE PAPER R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 39 | PP4083-1232P001 | GUIDE PAPER L | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 40 | PP4083-1231P001 | HOLDER PAPER | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 41 | PP4083-1192P001 | SENSOR PAPER EXIT | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 42 | 41802001 | Spring-Hopper_F | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 43 | 40638001 | Contact-CB | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 44 | 40638102 | CONN Cord-HV | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 46 | 40625401 | Fan | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 47 | PP4083-1137P001 | SPRING PRESSURE R | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 49 | 40562401 | Guide Sheet | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 51b | 41982502 | Heat Assy | 1 | 5 | 10 | 20 | 230V | | - |

| Rev | Unit Name | No. | Part No. | Part Name | Q'ty /Unit | Recommended Q'ty/Year | | | Remarks | Del/ Add | ks for environment |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | per 500 | per 1000 | per 2000 | | | |
| | PRINTER BASE FRAME UNIT | 52 | 40034001 | SPRING STOPPER | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 53 | PB4091-6047P001 | CAUTION LABEL T | 1 | 3 | 6 | 12 | 230V | | - |
| | PRINTER BASE FRAME UNIT | 54 | 40688601 | Washer-TR | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 55 | 40710301 | Guide-Gear T | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 56 | 40634701 | Bearing-Gear | 1 | 3 | 6 | 12 | | | - |
| | PRINTER BASE FRAME UNIT | 57 | LP-6401-B1 | TYING CORD | 1 | 3 | 6 | 12 | | | - |
| | PRINTER HEAT ASSY, | 1 | PB4083-1202P001 | ROLLER HEAT | 1 | 5 | 10 | 20 | | | - |
| | PRINTER HEAT ASSY, | 2b | 41524002 | Lamp-Halogen | 1 | 5 | 10 | 20 | 230V | | - |
| | PRINTER HEAT ASSY, | 3 | PB4083-1204P001 | THERMOSTAT | 1 | 5 | 10 | 20 | | | - |
| | PRINTER HEAT ASSY, | 4 | PB4083-1205P001 | THERMISTOR | 1 | 5 | 10 | 20 | | | - |
| | PRINTER HEAT ASSY, | 5 | PB4083-1213P001 | CORD HEAT | 1 | 5 | 10 | 20 | | | - |
| | CABLES | 1 | 40635401 | CONN Cord-Wire(AC) | 1 | 3 | 6 | 12 | | | - |
| | CABLES | 2 | 40040001 | CONN Cord-Wire(OPE) | 1 | 3 | 6 | 12 | | | - |
| | CABLES | 3 | 40040201 | CONN Cord-Wire(CIS) | 1 | 3 | 6 | 12 | | | - |
| | CABLES | 4 | 40040301 | CONN Cord-Wire(PC1/2) | 1 | 3 | 6 | 12 | | | - |
| | CABLES | 5 | 105A1070C0003 | TFC-20-10-10 | 1 | 3 | 6 | 12 | CIS-46F or R46 | | - |
| | CABLES | 6 | 105A1070C0004 | TFC-23-11-14 | 1 | 3 | 6 | 12 | CPE-46F or R46 | | - |
| | CABLES | 7 | 105A1073C4002 | SSC-40-12 | 1 | 3 | 6 | 12 | HV-46F or R46 | | - |
| | CABLES | 9 | 1051003C0001 | FPC-25-20 | 1 | 3 | 6 | 12 | LED-46F or R46 (OKIFAX 4550:1 OKIOFFICE87:2) | | - |
| | CABLES | 14 | 105A1068C1004 | SFC-8 | 1 | 3 | 6 | 12 | For TEL/LINE Cord use | | - |
| | CABLES | 15 | 40687701 | Cord-Flat (SUMI CARD) | 1 | 3 | 6 | 12 | P6L-46F or R46 | | - |
| | CABLES | 16 | 1051005C0003 | RFC-8 | 1 | 3 | 6 | 12 | OKIOFFICE87 | | - |
| | CABLES | 17 | LP-6401-B1 | TYING CORD | 1 | 3 | 6 | 12 | | | - |